

HARDWARE PARTS LIST



(qty 1)
Casita Breeze Back Wall Frame



(qty 1)
Travel Bag



(qty 1)
800W Electric Air Pump



(qty 1)
Rope & Stake Set
Includes: 4 Stakes, 4 Rope
Bundles, & 1 Drawstring Bag



(qty 1)
Replacement Valve Set



(qty 2)
TPU Repair Patches


BREEZE 13FT INFLATABLE WALL

INFLATABLE DISPLAYS


PRODUCT CODE: BRZ-WALL13




SET UP INSTRUCTIONS




1. LAY WALL FLAT OUT ON THE GROUND MAKING SURE THE VELCRO STRIP IS FACING UP.




2. MAKE SURE BOTTOM VALVES ARE TIGHTENED AND OPEN TOP INLET VALVE



3. INSERT AIR PUMP HOSE INTO INPUT VALVE ON FRAME AND POWER PUMP ON TO INFLATE. FRAME INFLATION SHOULD ONLY TAKE A COUPLE MINUTES.



4. ONCE FULLY INFLATED CLOSE THE INPUT VALVE COVER.



5. TO INSTALL THE GRAPHIC, BEGIN BY SECURING EACH CORNER, THEN WORK YOUR WAY AROUND THE SIDES TO ENSURE AN EVEN FIT.

