

SET UP INSTRUCTIONS

1. INSERT HORIZONTAL POLES INTO THE SIDE OPENINGS OF TOP POLE POCKET OF GRAPHIC AND MAKE SURE THE POLES ARE CONNECTED IN THE MIDDLE.



2. SLIDE VERTICAL POLES INTO THE SIDE POLE POCKETS FROM THE BOTTOM. MAKE SURE TOP OF VERTICAL POLES ATTACH TO L CORNER OF HORIZONTAL POLES TO COMPLETE FRAME ASSEMBLY

3. ATTACH BRACKETS TO TENT LEGS

4. SLIDE POLES ONTO TENT LEG BRACKETS AND SECURE BUNGEEES