

10FT CASITA CANOPY TENTS™ STEEL KIT 2

TENTS


PRODUCT CODE: CASTL-10-KIT2



Black Trim



White Trim



PRODUCT DESCRIPTION

The 10ft Steel Casita Kit 2 is a streamlined, fully enclosed canopy solution designed for brands that require maximum graphic coverage and a clean, professional footprint. Built around a durable 10ft steel Casita tent frame, this kit delivers exceptional strength, stability, and dependable performance for repeated use. The steel construction provides a solid, cost-effective structure ideal for both indoor and outdoor environments, offering reliable support and a clean, professional appearance that complements high-quality printed graphics and branded displays.

Included with the kit are three single-sided Casita back walls, creating a more enclosed structure that enhances branding visibility while helping to reduce visual distractions and provide added protection from wind and sun during outdoor events. A standard tent travel bag is also included to keep components organized and protected during transport and storage. Together, these elements make the 10ft Steel Casita Kit 2 a practical and professional solution for events, promotions, and activations that demand strong structure, clear messaging, and efficient deployment.

DISPLAY DIMENSIONS	118.75"W x 135"H x 118.75"D
MIN/MAX HEIGHT	99" H to 135"H

GRAPHIC MATERIAL

Dye Sub Tent Fabric (UPF 50+ Rated Material)

TENT TOP GRAPHIC FINISHING

Hemmed around panels w/white or black trim on seams. Velcro sewn to insides of each valance corner and reinforcement sewn inside of peak.

BACK WALL GRAPHIC FINISHING

Hemmed around perimeter with white or black trim to match tent top. Hook and loop straps are added along the top and sides to attach wall to tent frame.

DISPLAY CONSTRUCTION

Steel tent frame w/28mm dia square legs & plastic components

TENT SHIPPING WEIGHTS & DIMENSIONS

Shipping Weight	63 lbs (tent frame+ top + bag)
Shipping Dimensions	63"L x 11"W x 11"H

BACK WALL SHIPPING WEIGHTS & DIMENSIONS

Shipping Weight	18 lbs (3 backwalls)
Shipping Dimensions	Polybag

WIND SPEED RATING	20 - 28 mph
--------------------------	-------------

PARTS LIST TENT



(qty 1)
Tent Frame



(qty 1)
Travel Bag

AVAILABLE ACCESSORIES



10ft Wheeled Bag
CAS-BAGWHL



Falcon Flag Connector 0°
FAL-FMOD (flag mount)
FAL-FLGCNCT (back plate)



La Caja Hardcase
LACAJA



Ropes & Stakes
CAS-RS



Sand Bag Cover
CAS-SBAG



Plastic Water Base
CAS-SQR-BASE

SET UP INSTRUCTIONS

Step 1

Take your frame and slightly expand it open to expose the corner bars.



Step 2

Take your canopy graphic and place it on top of the frame.




Step 3

Adhere each corner of the canopy to each corner of the frame. Inside each corner of the canopy, there is a strip of loop Velcro sewn to it and each corner of the frame has a strip of hook Velcro.



Step 4

With the canopy securely in position, expand the frame until the corner latches lock into place.




Step 5

Increase the height by extending the lower legs.



Step 6

Pull each leg down until the latch locks into place.



Step 7

Locate the spindle under the canopy, in the middle of the frame. Pull the lever out and rotate to extend the upper peak pole. The dome cap will push out the canopy creating tension to flush out any loose areas.




Step 8

The install is complete.



ATTACHING BACK WALL



Back Wall Top & Side Straps

1. Set up tent
2. Attach top straps of back wall to the horizontal "X Braces" of tent frame (See photo to left)
3. Once all top straps are connected to the frame, attach the straps on the left and right sides of the wall to the tent legs.
4. Make sure to remove back wall prior to collapsing frame for storage/transport.