


SHOWBIRD 120 20 X 10 CONFIGURATION E

SHOWBIRD 120 MODULAR LIGHTBOX


PRODUCT CODE: SB120-2010-E



PARTS LIST




(qty 2) Showbird 120 Modular
Lightbox 300x240 Hardware Only
SKU: SB120-300x240
Each frame includes 1 travel bag




(qty 6) Showbird 120 Modular
Lightbox 100x240 Hardware Only
SKU: SB120-100x240
Each frame includes 1 travel bag




(qty 8) Straight Connector
SKU: SB120-SCON




(qty 4) Corner Connector Foot
SKU: SB120-FOOT-90




(qty 4) Corner Connector Top
SKU: SB120-ACC-90



(qty 2) Monitor Mount
SKU: SB120-TV



(qty 4) Shelf - Inside Mount
SKU: SB120-SHELF-I



(qty 1) Door Kit
SKU: SB120-DOOR

SHOWBIRD 120 20 X 10 CONFIGURATION E


SHOWBIRD 120 MODULAR LIGHTBOX

PRODUCT CODE: SB120-2010-E



SET UP INSTRUCTIONS SB120-100X240



SET UP EACH FRAME INDIVIDUALLY BEFORE CONNECTING




SHOWBIRD 120 20 X 10 CONFIGURATION E

SHOWBIRD 120 MODULAR LIGHTBOX


PRODUCT CODE: SB120-2010-E



01 Connect the corner profile.



02 Connecting side profiles; Connect the pole to the side profile.



03 Connect the power plug.


SHOWBIRD 120 20 X 10 CONFIGURATION E

SHOWBIRD 120 MODULAR LIGHTBOX

PRODUCT CODE: SB120-2010-E





SET UP INSTRUCTIONS SB120-300X240




SHOWBIRD 120 20 X 10 CONFIGURATION E

SHOWBIRD 120 MODULAR LIGHTBOX


PRODUCT CODE: SB120-2010-E




01 Connect the corner profile.



02 Connecting side profiles; Connect the pole to the side profile.



03 Connect the pole.



04 Connect the power plug.


SHOWBIRD 120 20 X 10 CONFIGURATION E

SHOWBIRD 120 MODULAR LIGHTBOX

PRODUCT CODE: SB120-2010-E




CONFIGURATION ASSEMBLY




SB120-SCON

UNSCREW THE SB120-SCON AND SLIDE THEM THROUGH THE ACCESS HOLES ON THE TOP AND BOTTOM OF THE VERTICAL PROFILES. SCREW PIECES TOGETHER TO SECURE. REPEAT FOR ALL 100 TO 300 FRAME CONNECTIONS.



SB120-DOOR

SB120-DOOR ATTACHES TO THE TOP & BOTTOM OF SB120-100X240 FRAME. INSTALL ON BOTH ENDS OF THE ROOM




SHOWBIRD 120 20 X 10 CONFIGURATION E

SHOWBIRD 120 MODULAR LIGHTBOX

PRODUCT CODE: SB120-2010-E




SB120-TV INSTALLATION



SB120-TV

1. ATTACH THE HANGING ROD TO THE INSIDE OF THE VERTICAL PROFILES AT THE DESIRED HEIGHT.
2. HANG THE TV MOUNTING PLATE ONTO THE ROD.
3. INSTALL THE GRAPHIC OVER THE MOUNTING PLATE.
4. POSITION THE TV WALL MOUNT PLATE OVER THE GRAPHIC AND MARK THE LOCATIONS FOR THE MOUNTING HOLES.
5. CAREFULLY CREATE HOLES IN THE GRAPHIC AT THE MARKED LOCATIONS.
6. SECURE THE WALL MOUNT PLATE TO THE SB120-TV THROUGH THE GRAPHIC.
7. ATTACH THE MOUNTING HARDWARE TO THE TV, THEN HANG THE TV ONTO THE WALL MOUNT PLATE.

NOTE: THE TV DOES NOT MOUNT DIRECTLY TO THE SB120-TV.




SHOWBIRD 120 20 X 10 CONFIGURATION E

SHOWBIRD 120 MODULAR LIGHTBOX

PRODUCT CODE: SB120-2010-E



SB120-TV INSTALLATION



SB120-SHELF-I

1. SLIDE THE SHELF SUPPORTS INTO THE SLOTS ON THE VERTICAL PROFILES.
2. POSITION THE GRAPHIC ONTO THE FRAME AND MARK WHERE SLITS ARE NEEDED TO ALLOW THE SHELF SUPPORTS TO PASS THROUGH.
3. CAREFULLY CUT SLITS IN THE GRAPHIC AT THE MARKED LOCATIONS.
4. INSTALL THE GRAPHIC ONTO THE FRAME.
5. PLACE THE SHELF ONTO THE INSTALLED SHELF SUPPORTS.

NOTE: SHELF KITS ARE ONLY COMPATIBLE WITH SB120-100X240 FRAMES.


SHOWBIRD 120 20 X 10 CONFIGURATION E

SHOWBIRD 120 MODULAR LIGHTBOX

PRODUCT CODE: SB120-2010-E



TRAVEL BAG STORAGE SB120-300X240



TRAVEL BAG STORAGE SB120-100X240

