


Product Part



- A** Battery Indicator
- B** Light Cover
- C** **D** Rope Hole
- E** Waterproof Switch (luminous)
- F** Waterproof Cap (unscrew it to recharge)
- G** USB Output
- H** Type-C charging and discharging
- I** Tripod Mount (1/4"-20 thread)

Product Instructions

1. While off, press it to turn the light on (previous setting will be memorized)
2. While on:
 - ① Single press: cycle through level 1, level 2, level 3 and off.
 - ② Double press: cycle through cool white, natural white, mosquito repellent light.
 - ③ Long Press: turn the light off, current setting will be memorized.

Battery Life

1. The battery life is 5-50 hours, it varies depending the level of brightness.
2. If it is used as a powerbank, the battery life varies depending the connected devices.

Mode	Battery Life
Level 1 of white, natural white, warm white	~50hrs
Level 2 of white, natural white, warm white	~11hrs
Level 3 of white, natural white, warm white	~5hrs
Level 1 of mosquito repellent	~45hrs
Level 2 of mosquito repellent	~12hrs
Level 3 of mosquito repellent	~6hrs


Low Battery Warning

The first blue LED will flash to remind users to charge the battery when the battery is low.

Charging Indicator

- 1. The blue LED light will flash 4 times during charging.
- 2. When fully charged, the blue LED light will glow steady. Please disconnect the power supply in time.

Power Status Indicator



Blue LED Light	Power
1 LED is on	0%~25%
2 LEDs are on	25%~50%
3 LEDs are on	50%~75%
4 LEDs are on	75%~100%