WALLBOX 15FT X 8FT

PRODUCT CATEGORY: WALLBOX DISPLAYS

PRODUCT CODE: WB-15X8













PRODUCT DESCRIPTION

Introducing the new Wallbox Fabric Display, a portable unlike anything you've ever seen. Your exhibitors will be in awe of it's mighty size! You might need a friend to help you set it up, but don't let this giant dissuade you it's completely toolless! Using the same framework as our line of Skybox Hanging Banners, set up is a snap! With push button snap locks, the tubes connect together without the need for tools. Custom dye sublimated fabric graphics fully wrap the entire frame. We offer two graphic options for the wallbox. Double sided graphic option includes dye sub printed front panel, back panel, and end caps, with plain black fabric on the top and bottom. Single sided graphic option includes dye sub printed front panel and end caps with your choice of blank white or black fabric for the backside, top, and bottom. The graphic is finished pillowcase style with a zipper at the bottom for easy installation and a clean finished look. A travel bag is included to transport and store your display in between events.

DISPLAY DIMENSIONS	180"W x 96"H x 18"D
GRAPHIC SIZE SINGLE	107.75"W x 48.25"H (50% Scale)
GRAPHIC SIZE DOUBLE	98.625"W x 24.125"H (25% Scale)

GRAPHIC MATERIAL

Dye Sublimated Stretch Fabric

GRAPHIC FINISHING


Pillowcase graphic finishing with zipper closure along the top. Double sided has printed front, back and end cap panels, with stock black fabric on top and bottom. Single sided has printed front and end caps with your choice of blank white or black back panel with matching top and bottom panels.

DISPLAY CONSTRUCTION

30mm aluminum tubing with plastic connectors

SHIPPING WEIGHTS & DIMENSIONS Shipping Weight | 49 lbs (Graphic Pau

Shipping Weight	49 lbs (Graphic Package) 37 lbs (Hardware Only) 12 lbs (Graphic Only)
Shipping Dimensions	68" L x 19" W x 12" H (Graphic Package) 68" L x 19" W x 12" H (Hardware Only) Poly Bag (Graphic Only)


















PARTS LIST















SET UP INSTRUCTIONS

OUTER FRAME ASSEMBLY




INNER FRAME ASSEMBLY






Define the location of the plastic connectors



Attach the female tube in the right position and push the button, and slide the tube



Push the female tube until the button



Press button & insert swaged end into receiving end of tubing



Push the female tube until the button snaps